

OEM_NAME	LEVEL1	LEVEL2	LEVEL3	LEVEL4	LEVEL5	Min Amt	MAX_AMOUNT	PRODUCT_SKU_CODE
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	14 PS	SMS6HVI01I	53000	72490	SMS6HVI01I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	13 PS	SMS66GW01I	39000	52990	SMS66GW01I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	13 PS	SMS66GI01I	42000	56990	SMS66GI01I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	13 PS	SMS6ITI00I	45000	60990	SMS6ITI00I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	14 PS	SMS46KI03I	51000	68990	SMS46KI03I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	13 PS	SMS2ITW00I	38000	51990	SMS2ITW00I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	13 PS	SMS6ITW00I	42000	57490	SMS6ITW00I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	13 PS	SMS6ITI01I	45000	61490	SMS6ITI01I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	14 PS	SMS6HVI00I	54000	72990	SMS6HVI00I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	14 PS	SMS6ZCW42E	89000	120990	SMS6ZCW42E
Bosch / Bosch Spl	Siemens	Dishwasher	Dishwasher	13 PS	SN256W01GI	39000	53990	SN256W01GI
Bosch / Bosch Spl	Siemens	Dishwasher	Dishwasher	13 PS	SN256I01GI	42000	57990	SN256I01GI
Bosch / Bosch Spl	Siemens	Dishwasher	Dishwasher	13 PS	SN25IW00TI	43000	58490	SN25IW00TI
Bosch / Bosch Spl	Siemens	Dishwasher	Dishwasher	13 PS	SN25II00TI	46000	62490	SN25II00TI
Bosch / Bosch Spl	Siemens	Dishwasher	Dishwasher	14 PS	SN25HI00VI	59000	79990	SN25HI00VI
Bosch / Bosch Spl	Siemens	Dishwasher	Dishwasher	15 PS	SN27ZI00VI	93000	125990	SN27ZI00VI
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	14 PS	SMV46KX01I	62000	83990	SMV46KX01I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	13 PS	SMI4IVS00I	59000	80990	SMI4IVS00I
Bosch / Bosch Spl	Bosch	Dishwasher	Dishwasher	14 PS	SMV6HVX00I	65000	88990	SMV6HVX00I
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOE651W0IN	12395	24790	WOE651W0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOE653D0IN	13395	26790	WOE653D0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOE701D0IN	13795	27590	WOE701D0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOE703S0IN	14345	28690	WOE703S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOE651D0IN	13095	26190	WOE651D0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOE701W0IN	13495	26990	WOE701W0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOI654M0IN	15145	30290	WOI654M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOI703M0IN	15495	30990	WOI703M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOI705R0IN	17395	34790	WOI705R0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOI705B0IN	17395	34790	WOI705B0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOE751W0IN	14495	28990	WOE751W0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOE751D0IN	14995	29990	WOE751D0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOI753S0IN	16045	32090	WOI753S0IN

Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOI753M0IN	16320	32640	WOI753M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOI755R0IN	18145	36290	WOI755R0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOE802D1IN	16395	32790	WOE802D1IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOI804M0IN	19220	38440	WOI804M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOI803S0IN	19470	38940	WOI803S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOI653S0IN	14845	29690	WOI653S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOE753M0IN	15245	30490	WOE753M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	9.0	WOI904S0IN	20995	41990	WOI904S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	9.0	WOI905R0IN	22595	45190	WOI905R0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	10.0	WOI104M0IN	23145	46290	WOI104M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	10.0	WOI105B0IN	24195	48390	WOI105B0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOE802D7IN	15745	31490	WOE802D7IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOE802S7IN	15995	31990	WOE802S7IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOE802B7IN	16245	32490	WOE802B7IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOI805B7IN	19745	39490	WOI805B7IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	11 kg	WOI114S0IN	23995	47990	WOI114S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	11 kg	WOI115B0IN	24245	48490	WOI115B0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOI804M7IN	17745	35490	WOI804M7IN
Bosch / Bosch Spl	Bosch	Refrigerator	Bottom Freezer	415 L	KGN46XL40I	48000	77580	KGN46XL40I
Bosch / Bosch Spl	Bosch	Refrigerator	Side By Side	658 L	KAN92VS30I	67554	112590	KAN92VS30I
Bosch / Bosch Spl	Siemens	Refrigerator	Side By Side	658 L	KA92NVS30I	67554	112590	KA92NVS30I
Bosch / Bosch Spl	Siemens	Refrigerator	Side By Side	655 L	KA92NLB35I	130302	217170	KA92NLB35I
Bosch / Bosch Spl	Bosch	Refrigerator	TF Max Flex	332 L	CMC33S05NI	38500	58190	CMC33S05NI
Bosch / Bosch Spl	Bosch	Refrigerator	TF Max Flex	332 L	CMC33WT5NI	38500	58690	CMC33WT5NI
Bosch / Bosch Spl	Bosch	Refrigerator	TF Max Flex	332 L	CMC33K05NI	38500	59390	CMC33K05NI
Bosch / Bosch Spl	Bosch	Refrigerator	TF Max Flex	364 L	CMC36S05NI	44500	67590	CMC36S05NI
Bosch / Bosch Spl	Bosch	Refrigerator	TF Max Flex	364 L	CMC36WT5NI	43000	68290	CMC36WT5NI
Bosch / Bosch Spl	Bosch	Refrigerator	TF Max Flex	364 L	CMC36K05NI	44500	68790	CMC36K05NI
Bosch / Bosch Spl	Bosch	Refrigerator	Bottom Freezer	559 L	KGN56XI40I	64500	97020	KGN56XI40I
Bosch / Bosch Spl	Bosch	Refrigerator	Bottom Freezer	559 L	KGN56LB41I	70000	102870	KGN56LB41I
Bosch / Bosch Spl	Bosch	Refrigerator	Bottom Freezer	559 L	KGN56CX41I	70000	100990	KGN56CX41I
Bosch / Bosch Spl	Bosch	Refrigerator	Bottom Freezer	559 L	KGN56LB42I	74500	105990	KGN56LB42I
Bosch / Bosch Spl	Bosch	Refrigerator	Side By Side	658 L	KAN92VI35I	77652	129420	KAN92VI35I

Bosch / Bosch Spl	Bosch	Refrigerator	Side By Side	655 L	KAN92LB35I	114750	191250	KAN92LB35I
Bosch / Bosch Spl	Siemens	Refrigerator	Bottom Freezer	559 L	KG56NXX40I	66500	102330	KG56NXX40I
Bosch / Bosch Spl	Siemens	Refrigerator	Bottom Freezer	559 L	KG56NCX41I	70000	105490	KG56NXX40I
Bosch / Bosch Spl	Bosch	Refrigerator	Side By Side	Side By Side	KFN96PX91I	184788	307980	KFN96PX91I
Bosch / Bosch Spl	Bosch	Refrigerator	Side By Side	Side By Side	KFN86AA66I	117450	195750	KFN86AA66I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTN27S03NI	27000	37490	CTN27S03NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTN27BT3NI	27000	38390	CTN27BT3NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTN27B13NI	25500	38390	CTN27B13NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTN27W13NI	25500	38390	CTN27W13NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTN27W330I	25500	38390	CTN27W330I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTC27W13EI	28500	41590	CTC27W13EI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTC27M03NI	29000	42290	CTC27M03NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTC27B23EI	29000	42390	CTC27B23EI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTC27W24EI	31500	46290	CTC27W24EI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	263 L	CTC27BT4NI	32000	47190	CTC27BT4NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	290 L	CTC29S03NI	29315	44290	CTC29S03NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	290 L	CTC29W13NI	28500	44290	CTC29W13NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	290 L	CTC29W24EI	32007	48390	CTC29W24EI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	290 L	CTC29S04DI	33535	50690	CTC29S04DI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	358 L	CTC35BT3NI	34000	59390	CTC35BT3NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	358 L	CTC35S03NI	38000	59390	CTC35S03NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	358 L	CTC35B23EI	34000	59890	CTC35B23EI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	358 L	CTC35S03DI	39000	62890	CTC35S03DI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTC27S031I	26000	42790	CTC27S031I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	269 L	CTC29BT31I	29315	46490	CTC29BT31I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTN27S031I	26000	38590	CTN27S031I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTN27BT31I	25000	39490	CTN27BT31I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTN27B131I	25000	39490	CTN27B131I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTN27W131I	25000	39490	CTN27W131I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTC27W131I	26674	42790	CTC27W131I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTC27K031I	28154	43590	CTC27K031I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTC27B231I	27500	43690	CTC27B231I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTC27W241I	28614	47690	CTC27W241I

Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	243 L	CTC27BT41I	29154	48590	CTC27BT41I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	269 L	CTC29S031I	30000	45590	CTC29S031I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	269 L	CTC29W131I	28000	45590	CTC29W131I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	269 L	CTC29W241I	30000	49790	CTC29W241I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	269 L	CTC29S041I	31300	52190	CTC29S041I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	334 L	CTC35BT31I	34000	59390	CTC35BT31I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	334 L	CTC35S032I	37000	59390	CTC35S032I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	334 L	CTC35B231I	34000	59890	CTC35B231I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	334 L	CTC35S031I	38500	62890	CTC35S031I
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	368 L	CTC39S03NI	46000	70690	CTC39S03NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	368 L	CTC39K03NI	46500	74590	CTC39K03NI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	368 L	CTC39S03DI	48500	71390	CTC39S03DI
Bosch / Bosch Spl	Bosch	Refrigerator	Top Freezer	290 L	CTC29BT3NI	31000	45190	CTC29BT3NI
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOE651W0IN	12395	24790	WOE651W0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOE653D0IN	13395	26790	WOE653D0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOE701D0IN	13795	27590	WOE701D0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOE703S0IN	14345	28690	WOE703S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WLJ2016HIN	23214	38690	WLJ2016HIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2426TIN	30174	50290	WAJ2426TIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.5	WAJ2846IIN	35809	55090	WAJ2846IIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ24269IN	35419	54490	WAJ24269IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.0	WLJ20161IN	22254	37090	WLJ20161IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2006TIN	29274	48790	WAJ2006TIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.0	WLJ2016EIN	19734	32890	WLJ2016EIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ24261IN	30674	47190	WAJ24261IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOE651D0IN	13095	26190	WOE651D0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOE701W0IN	13495	26990	WOE701W0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.5	WAJ2446IIN	35094	53990	WAJ2446IIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.0	WLJ2046WIN	21054	35090	WLJ2046WIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.0	WLJ2046SIN	22134	36890	WLJ2046SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WLJ2026EIN	24774	41290	WLJ2026EIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WAJ2016HIN	26574	44290	WAJ2016HIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WAJ2426HIN	27774	46290	WAJ2426HIN

Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WAJ2426IIN	27774	46290	WAJ2426IIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2006WIN	28554	47590	WAJ2006WIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2426WIN	29274	48790	WAJ2426WIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.5	WAJ2426EIN	30219	46490	WAJ2426EIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.5	WAJ2446HIN	31324	48190	WAJ2446HIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.5	WAJ2446DIN	32494	49990	WAJ2446DIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ24267IN	34769	53490	WAJ24267IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ2426GIN	36134	55590	WAJ2426GIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ2846WIN	36654	56390	WAJ2846WIN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOI654M0IN	15145	30290	WOI654M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOI703M0IN	15495	30990	WOI703M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOI705R0IN	17395	34790	WOI705R0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.0	WOI705B0IN	17395	34790	WOI705B0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOE751W0IN	14495	28990	WOE751W0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOE751D0IN	14995	29990	WOE751D0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOI753S0IN	16045	32090	WOI753S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOI753M0IN	16320	32640	WOI753M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOI755R0IN	18145	36290	WOI755R0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOE802D1IN	16395	32790	WOE802D1IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOI804M0IN	19220	38440	WOI804M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOI803S0IN	19470	38940	WOI803S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	6.5	WOI653S0IN	14845	29690	WOI653S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	7.5	WOE753M0IN	15245	30490	WOE753M0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WAJ24168IN	25914	43190	WAJ24168IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WAJ24169IN	26874	44790	WAJ24169IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ24262IN	30414	50690	WAJ24262IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2446SIN	31494	52490	WAJ2446SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2446MIN	31914	53190	WAJ2446MIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.5	WAJ2426VIN	33794	51990	WAJ2426VIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.5	WAJ2846DIN	35419	54490	WAJ2846DIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ2446KIN	36784	56590	WAJ2446KIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ2846SIN	37954	58390	WAJ2846SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ2846MIN	38279	58890	WAJ2846MIN

Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	7.0	WM12J16WIN	29694	49490	WM12J16WIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	7.0	WM12J26SIN	27714	46190	WM12J26SIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	7.0	WM12J46SIN	32994	54990	WM12J46SIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	7.5	WM14J46HIN	32299	49690	WM14J46HIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	7.5	WM14J46IIN	33859	52090	WM14J46IIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	8.0	WM12J26WIN	32299	49690	WM12J26WIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	8.0	WM14J46WIN	37434	57590	WM14J46WIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	8.0	WM14J46SIN	39514	60790	WM14J46SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WGA244AWIN	39000	71290	WGA244AWIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WGA244ASIN	41000	73490	WGA244ASIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	10.0	WGA254AVIN	45000	77590	WGA254AVIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	10.0	WGA254A0IN	43000	76090	WGA254A0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WAU28Q9SIN	43000	70890	WAU28Q9SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAT286H8IN	46534	71590	WAT286H8IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WAT286H9IN	43000	82490	WAT286H9IN
Bosch / Bosch Spl	Bosch	Washing Machine	Washer Dryer	10/6	WNA254U0IN	58000	97990	WNA254U0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Washer Dryer	9/6	WNA14400IN	50889	78290	WNA14400IN
Bosch / Bosch Spl	Bosch	Washing Machine	Washer Dryer	9/6	WNA14408IN	52319	80490	WNA14408IN
Bosch / Bosch Spl	Bosch	Washing Machine	Dryer	7.0	WTN86203IN	34314	52790	WTN86203IN
Bosch / Bosch Spl	Bosch	Washing Machine	Dryer	7.0	WTG86409IN	38084	58590	WTG86409IN
Bosch / Bosch Spl	Bosch	Washing Machine	Dryer	8.0	WTB86202IN	39189	60290	WTB86202IN
Bosch / Bosch Spl	Bosch	Washing Machine	Dryer	8.0	WTG8640SIN	43024	66190	WTG8640SIN
Bosch / Bosch Spl	Siemens	Washing Machine	Dryer	9.0	WT45W460IN	60899	93690	WT45W460IN
Bosch / Bosch Spl	Siemens	Washing Machine	Washer Dryer	10/6	WN54A2U0IN	58000	97990	WN54A2U0IN
Bosch / Bosch Spl	Siemens	Washing Machine	Washer Dryer	9/6	WN44A100IN	53944	82990	WN44A100IN
Bosch / Bosch Spl	Siemens	Washing Machine	Dryer	7.0	WT46N203IN	34314	52790	WT46N203IN
Bosch / Bosch Spl	Siemens	Washing Machine	Dryer	8.0	WT44B202IN	39319	60490	WT44B202IN
Bosch / Bosch Spl	Siemens	Washing Machine	Dryer	8.0	WT46G402IN	41399	63690	WT46G402IN
Bosch / Bosch Spl	Bosch	Washing Machine	Washer Dryer	10.5/6	WNA264U9IN	63694	97990	WNA264U9IN
Bosch / Bosch Spl	Siemens	Washing Machine	Washer Dryer	10.5/6	WN64A2U9IN	64344	98990	WN64A2U9IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	9.0	WOI904S0IN	20995	41990	WOI904S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	9.0	WOI905R0IN	22595	45190	WOI905R0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	10.0	WOI104M0IN	23145	46290	WOI104M0IN

Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	10.0	WOI105B0IN	24195	48390	WOI105B0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ2846GIN	38344	58990	WAJ2846GIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WAJ2846TIN	38669	59490	WAJ2846TIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2446NIN	31794	52990	WAJ2446NIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2446LIN	32214	53690	WAJ2446LIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WLJ2006HIN	25674	42790	WLJ2006HIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WLJ2006DIN	26394	43990	WLJ2006DIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WLJ2026HIN	26754	44590	WLJ2026HIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.0	WLJ2026WIN	23334	38890	WLJ2026WIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.0	WLJ2026SIN	24354	40590	WLJ2026SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WLJ2026IIN	25974	43290	WLJ2026IIN
Bosch / Bosch Spl	Bosch	Washing Machine	Washer Dryer	10.5/6	WNA2E4U1IN	64994	99990	WNA2E4U1IN
Bosch / Bosch Spl	Siemens	Washing Machine	Washer Dryer	10.5/6	WNE4A2UPIN	65644	100990	WNE4A2UPIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.0	WLJ2016TIN	23274	38790	WLJ2016TIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WLJ2026DIN	26514	44190	WLJ2026DIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2016SIN	28254	47090	WAJ2016SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ2416EIN	25314	42190	WAJ2416EIN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOE802D7IN	12596	31490	WOE802D7IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOE802S7IN	12796	31990	WOE802S7IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOE802B7IN	12996	32490	WOE802B7IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	8.0	WOI805B7IN	15796	39490	WOI805B7IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	11 kg	WOI114S0IN	18996	47490	WOI114S0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Top Loader	11 kg	WOI115B0IN	19396	48490	WOI115B0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WAJ20062IN	28919	44490	WAJ20062IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WAJ20068IN	31194	47990	WAJ20068IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WAJ20266IN	31844	48990	WAJ20266IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	6.5	WAJ24265IN	30544	46990	WAJ24265IN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	8.0	WG34A200IN	36500	57990	WG34A200IN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	8.0	WG34A20PIN	38500	59990	WG34A20PIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	8.0	WG34A20SIN	37500	59490	WG34A20SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WGA12200IN	34293	48990	WGA12200IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WGA12208IN	36393	51990	WGA12208IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WGA12209IN	35693	50990	WGA12209IN

Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WGA1220PIN	35693	50990	WGA1220PIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WGA1220SIN	35343	50490	WGA1220SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	7.0	WGA1220TIN	36743	52490	WGA1220TIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WGA1320SIN	35500	54990	WGA1320SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WGA1320TIN	36500	56490	WGA1320TIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WGA13400IN	35419	54490	WGA13400IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WGA1340SIN	36394	55990	WGA1340SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WGA1340TIN	37369	57490	WGA1340TIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WGA2340PIN	37044	56990	WGA2340PIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WGA2341PIN	37694	57990	WGA2341PIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	8.0	WGA2341SIN	37369	57490	WGA2341SIN
Bosch / Bosch Spl	Bosch	Washing Machine	Dryer	8.0	WPG23108IN	42894	65990	WPG23108IN
Bosch / Bosch Spl	Bosch	Washing Machine	Dryer	8.0	WPG23100IN	40944	62990	WPG23100IN
Bosch / Bosch Spl	Siemens	Washing Machine	Dryer	8.0	WP31G208IN	42894	65990	WP31G208IN
Bosch / Bosch Spl	Siemens	Washing Machine	Dryer	8.0	WP31G200IN	40944	62990	WP31G200IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WGA24400IN	40749	62690	WGA24400IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WGA2440XIN	41724	64190	WGA2440XIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WGA244AXIN	45364	69790	WGA244AXIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WGA244A0IN	45364	69790	WGA244A0IN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	9.0	WG44A2A0IN	45884	70590	WG44A2A0IN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	9.0	WG44A20XIN	43804	67390	WG44A20XIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	9.0	WG44A2AXIN	47444	72990	WG44A2AXIN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WAU28PH0IN	51084	78590	WAU28PH0IN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	9.0	WM14UPH0IN	53164	81790	WM14UPH0IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	10.0	WGA254AXIN	48484	74590	WGA254AXIN
Bosch / Bosch Spl	Siemens	Washing Machine	Front Load	10.0	WG54A2AXIN	50564	77790	WG54A2AXIN
Bosch / Bosch Spl	Siemens	Washing Machine	Washer Dryer	9/6	WN44A108IN	55244	84990	WN44A108IN
Bosch / Bosch Spl	Siemens	Washing Machine	Dryer	9.0	WP41G200IN	44519	68490	WP41G200IN
Bosch / Bosch Spl	Bosch	Washing Machine	Dryer	9.0	WPG24100IN	44519	68490	WPG24100IN
Bosch / Bosch Spl	Siemens	Washing Machine	Dryer	9.0	WP41G208IN	46794	71990	WP41G208IN
Bosch / Bosch Spl	Bosch	Washing Machine	Dryer	9.0	WPG24108IN	46794	71990	WPG24108IN
Bosch / Bosch Spl	Bosch	Washing Machine	Front Load	9.0	WGA1440XIN	37614	62690	WGA1440XIN
Bosch / Bosch Spl	Bosch	Cooking Appliances	Combi MW	36 L	COA565GS0I	71495	142990	COA565GS0I

Bosch / Bosch Spl	Bosch	Cooking Appliances	Combi MW	44 L	CMA585MSOI	69995	139990	CMA585MSOI
Bosch / Bosch Spl	Bosch	Cooking Appliances	MW	25 L	BEL550MSOI	29995	59990	BEL550MSOI
Bosch / Bosch Spl	Bosch	Cooking Appliances	MW	25 L	BEL553MSOI	34495	68990	BEL553MSOI
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	66 L	HBFO10BROZ	34995	69990	HBFO10BROZ
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	66 L	HBFO11BROZ	37495	74990	HBFO11BROZ
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	66 L	HBF113BROZ	44995	89990	HBF113BROZ
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	71 L	HBA534BSOZ	52995	105990	HBA534BSOZ
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	71 L	HBA574BROZ	59995	119990	HBA574BROZ
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	71 L	HBG633BS1J	69995	139990	HBG633BS1J
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	63 L	HBJ577EBOI	71995	143990	HBJ577EBOI
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	66 L	HBJ534EBOI	59495	118990	HBJ534EBOI
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	66 L	HBF532BAOI	48495	96990	HBF532BAOI
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	66 L	HBF133BROI	45995	91990	HBF133BROI
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	66 L	HBFO31BAOI	38495	76990	HBFO31BAOI
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	66 L	HBFO31BROI	36995	73990	HBFO31BROI
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	71 L	HBG7341B1	86995	173990	HBG7341B1
Bosch / Bosch Spl	Bosch	Cooking Appliances	Ovens	71 L	HSG7361B1	142495	284990	HSG7361B1
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PNC6B6B11I	15495	30990	PNC6B6B11I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PNH6B6B12I	18495	36990	PNH6B6B12I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	75 cm	PND7B6B10I	18495	36990	PND7B6B10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	75 cm	PNI7B6B10I	19995	39990	PNI7B6B10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PNC6B6F10I	21495	42990	PNC6B6F10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PNH6B6F10I	23495	46990	PNH6B6F10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	75 cm	PND7B6F10I	23995	47990	PND7B6F10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	75 cm	PNI7B6F10I	25495	50990	PNI7B6F10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	90 cm	PNF9B6F10I	27995	55990	PNF9B6F10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	90 cm	PNV9B6F10I	30995	61990	PNV9B6F10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PNH6B6F20I	25495	50990	PNH6B6F20I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	75 cm	PND7B6F20I	26995	53990	PND7B6F20I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	75 cm	PNI7B6F20I	27995	55990	PNI7B6F20I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	90 cm	PNF9B6F20I	32495	64990	PNF9B6F20I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	75 cm	PNI7B6G20I	32495	64990	PNI7B6G20I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	90 cm	PNV9B6F20I	34995	69990	PNV9B6F20I

Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	75 cm	PND7B6G20I	29995	59990	PND7B6G20I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	90 cm	PNF9B6G20I	37495	74990	PNF9B6G20I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	90 cm	PNV9B6G20I	39995	79990	PNV9B6G20I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	90 cm	PPQ9B6O90I	33450	66900	PPQ9B6O90I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	90 cm	PCQ9B5O90I	29650	59300	PCQ9B5O90I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PNH6B6B10I	15750	31500	PNH6B6B10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	POH6B6B10I	15100	30200	POH6B6B10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PNC6B6B10I	14500	29000	PNC6B6B10I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PGH6B5B60I	13000	26000	PGH6B5B60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PBH6C6B90I	12600	25200	PBH6C6B90I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PGC6B5B90I	12250	24500	PGC6B5B90I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PBH6C5B60I	11650	23300	PBH6C5B60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	90 cm	PCS9A5C90I	38100	76200	PCS9A5C90I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	70 cm	PMD83D31NX	25995	51990	PMD83D31NX
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	70 cm	PMD83D51NX	22995	45990	PMD83D51NX
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	30 cm	PIB375FB5I	32495	64990	PIB375FB5I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hobs	60 cm	PIE651BB5I	39995	79990	PIE651BB5I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	60 cm	DWKA68H60I	27495	54990	DWKA68H60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DWS97BA62I	34995	69990	DWS97BA62I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	60 cm	DWBA68J60I	21495	42990	DWBA68J60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	60 cm	DWBA68H60I	20995	41990	DWBA68H60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DWBA98J60I	24495	48990	DWBA98J60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DWBA98H60I	23995	47990	DWBA98H60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DWEA98H60I	36995	73990	DWEA98H60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	60 cm	DWGA68G60I	16495	32990	DWGA68G60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DWGA98G60I	18995	37990	DWGA98G60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DWBA98G60I	22995	45990	DWBA98G60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	60 cm	DWHA68G60I	16495	32990	DWHA68G60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DWHA98G60I	18995	37990	DWHA98G60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	60 cm	DWBA68G60I	19995	39990	DWBA68G60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	60 cm	DWKF68G60I	23995	47990	DWKF68G60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	60 cm	DWKA68G60I	25995	51990	DWKA68G60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DWKA98H60I	29495	58990	DWKA98H60I

Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DWKA98G60I	28495	56990	DWKA98G60I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	90 cm	DIB098G50I	37495	74990	DIB098G50I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Hoods	120 cm	DIB128G50I	41495	82990	DIB128G50I
Bosch / Bosch Spl	Bosch	Cooking Appliances	Cooking Range	60 cm	HXR390I50K	61495	122990	HXR390I50K
Bosch / Bosch Spl	Bosch	Cooking Appliances	Cooking Range	90 cm	HGVDA0Q59K	94995	189990	HGVDA0Q59K